

# POWERFLEX®

PART NUMBER

**PFF5-1102**

DESCRIPTION

**REAR TRAILING ARM FRONT BUSH INSERTS**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x POLYURETHANE BUSH INSERTS
- 1 x GREASE

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove bolt and drop arm down
2. Do not remove original bush
3. Check condition of original bush, if in poor condition replace bush
4. Fit insert between each side of original bush
5. Lift arm back into place and insert bolt
6. Ensure bolt is tightened to manufacture specification

