

POWERFLEX®

PART NUMBER

PFF1-506G

DESCRIPTION

FRONT UPPER ARM REAR - CAMBER ADJUST

INSTALLATION GUIDE

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel adjustable sleeves
- 2 x nylon washers
- 1 x C spanner
- 1 x grease



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove arm from the car.
2. Press out the original bush.
3. Clean any dirt and corrosion from the bore of the arm, chamfer the sharp edges.
4. Fit the bush into the arm from the inside pushing it towards the rear of the car.
5. Apply some of the supplied grease to the bore of the bush, the faces of the nylon washer and the outside of the sleeve.
6. Place the nylon washer over the sleeve, push the sleeve into the bush from the outside of the arm towards the middle.
7. Refit the arm to the car.
8. The sleeve is adjustable. The geometry will require setting up, adjust the angles with the supplied C spanner.

