

POWERFLEX®

PART NUMBER
PFF85-431

DESCRIPTION
FRONT STRUT TOP MOUNT BUSH -10mm

INSTALLATION GUIDE

Product Information: This kit is designed to lower the front suspension by 10mm.

Contents (parts per pack):

4 x Polyurethane bushes (2x A, 2x B)

1 x PTFE / Silicone grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;

- all safety precautions adhered to;

- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove front strut from the car.
2. Use a suitable spring compressor to remove the tension from the top mount.
3. Remove the original top mount.
4. The original bearing, cups and hardware need to be reused. Check the condition of the bearing, renew if required.
5. Refit the new top mount (Bush A) to the strut the same way as removed, the smaller outside diameter end fits towards the spring cup and bearing.
6. Refit the strut to the car.
7. From under the bonnet fit the original upper metal cup into the (Bush B) then bolt onto the top of the strut. *Note: Lupo vehicles do not require Bush B to be fitted.*
8. Tension all hardware to manufacturers recommended torque settings.

