



PART NUMBER  
**PFF85-602**

DESCRIPTION  
**FRONT ARM REAR BUSH**

### INSTALLATION GUIDE

#### **Contents (parts per pack):**

- 4 x bushes (2 A parts & 2 B parts)
- 1 x grease

*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove front arm from the car.
2. Leaving the sub frame in the car, completely remove the original bush. Make sure all dirt is removed from the bore of the hole on the sub frame.
3. To make the fitting of the B (purple) part easier, smear some soap onto the small chamfered lip, insert it into the hole from the front of the vehicle and push it through until the small chamfered lip clips out at the back face of the hole.
4. Push the black A part onto the hexagonal pin of the arm.
5. With the supplied grease lubricate the bore of the B purple bush and the outside of the A black bush.
6. Refit the arm onto the car.

Front of  
car



Insert bush this way



Fitted