



PART NUMBER
PFR42-613

DESCRIPTION
Rear Trailing Arm Inner Bush

INSTALLATION GUIDE

Product description:

This part replaces OEM part number RGX000840

Contents (parts per pack):

- 2 x bushes
- 2 x stainless steel sleeves
- 2 x washers
- 2 x circlips
- 1 x grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the inner side bush from the rear trailing arm.
2. Insert the new bush into the inner side bore of the arm by applying some washing-up liquid to help the bush slide through easily. Push bush all the way through till it is locked in properly. Fig A.
3. Apply some of the supplied grease to the bore of the bush and insert the sleeve into the bush. Fig A.
4. Place the washer into the sleeve and lock the bush and washer with the circlip. Fig B.
5. Re-fit the rear trailing arm to the car and tension all hardware to manufacturers recommended torque settings.



Insert sleeve into bore

Fig A



Fit washer and lock with circlip

Fig B