

# POWERFLEX®

PART NUMBER

**PFR79-103**

DESCRIPTION

**REAR LOWER WISHBONE ADJUSTER BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x bushes (2 x A, 2 x B)
- 2 x stainless steel sleeves
- 4 x bearings, (2 x 19mm, 2 x 25mm)
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original bush from the eyelet. Clean any rust, dirt or paint from the bore of the eyelet.
2. Fit the 19mm long bearing into the A bush and the 25mm long bearing into the B bush.
3. The eyelet is offset from the stud, fit the A bush and bearing into the side with the greater offset. Fit the B bush and bearing into the side with the smaller offset.
4. Apply some of the supplied grease to the bore of the bearings, outside of the sleeves and end faces of the bushes.
5. Push the sleeve into the bush.
6. Refit onto the car.

