



PART NUMBER

**PFF80-1002**

DESCRIPTION

**FRONT WISHBONE FRONT BUSH**

**INSTALLATION GUIDE**

**Product description:**

This part fits into wishbone OE numbers:  
13140037, 13140038, 0352 063, 0352 061.

**Contents (parts per pack):**

- 2 x Polyurethane A bushes
- 2 x Polyurethane B bushes
- 2 x Stainless steel sleeves
- 1 x Grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the original rubber bush and its outer shell from the wishbone of the arm and clean any dirt or corrosion from its bore.  
*Tip: it may be easier to cut the shoulder of the original bush to enable it to be pressed out more easily.*
2. Fit the A part polyurethane bush into the bore of the arm from the front of the car.
3. Fit the B part polyurethane bush into the bore of the arm from the rear of the car.
4. Apply some of the supplied grease to the bore of the bush and insert the stainless steel sleeve into the bush.
5. Re-fit the arm to the car and tighten hardware to manufacturers recommended torque settings.



Cut original bush shoulder to enable it to be pressed out.

