

INSTALLATION GUIDE

Product description:

This part replaces OEM part number 6E0199851D.

Contents (parts per pack):

1 x bushes	1 x stainless steel sleeve
1 x grease	1 x washer



Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the original bush from the arm. Be careful not to deform the arm.
2. Clean any dirt and corrosion from the bore in the arm. Remove any sharp edges from the bore of the arm.
3. Press the new bush into the arm. Make sure that the bush is facing in the right direction and the correct way up so that it can slot in the chassis (smaller slot to top). Check picture for aid.
4. Apply some of the supplied grease to the bore and end faces of the bush, push the stainless steel inner sleeve into the bush and slot the washer on the top surface .
6. Re-fit arm to the car. Tension all hardware to manufacturers recommended torque settings.

