

INSTALLATION GUIDE**Product description:**

This part replaces OEM part number 60611730.
Part fits Alfa Romeo GTV model year 1995 - 2002.

Contents (parts per pack):

2 x Bushes 1 x Grease

*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

**Fitting Instructions:**

1. Remove the anti roll bar from the car.
2. Using a drill, split open the bracket by drilling into the swedged section of the bracket as shown in Fig A.
2. Clean any dirt, corrosion and remove any sharp edges from the inside of the brackets.
3. Apply some of the supplied grease to the bore of the bush. Fit bush on the the bar. Fig B.
4. Re-fit anti roll bar back to the car and tension all hardware to manufacturers recommended torque settings.



Fig A.




Fig B.