



PART NUMBER

**PRF5-1825**

DESCRIPTION

**REAR DIFF REAR MOUNTING BUSH**

### INSTALLATION GUIDE

#### **Product description**

Countryman 4WD rear diff rear mounting bush, reduces diff movement for a more direct delivery of power to the road.

#### **Contents (parts per pack):**

- 4 x bushes
- 2 x stainless steel sleeves
- 2 x washers
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual. It is recommended that:*

- all work to be carried out by a licensed technician;
  - all safety precautions adhered to;
  - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

#### **Fitting Instructions:**

1. Remove the original bush from the rear diff rear mounting beam, clean any dirt and corrosion. Remove any sharp edges from around the bore.
2. Fit the new polyurethane bushes, one half from the top face and another from the lower face.
3. Apply some of the supplied grease to the bore of the bush and push the stainless steel sleeve through.
4. Refit the mounting beam to the car, fitting the new washers on to the lower bush for support.

