



VW T5 TRANSPORTER 2.5 TURBO BAYONET COUPLER FITTING INSTRUCTIONS

1. Remove the U shaped clip from the turbo housing as shown below and then pull the coupler out of the turbo housing.
2. Loosen the hose clamp on the silicone/rubber hose and remove the OEM coupler.
3. Refit in the reverse order.



ENGINEERED FOR PERFORMANCE

